CSE3003 Lab 11

- Job Fernandez 19BCD7154

Experiment: DHCP Server

Steps:

- 1. Place a Server PT in the network
- 2. Place three switches and 5 PCs as shown in the diagram
- 3. Click on Switch0
 - a. Insert PT-Switch-NM-1CFE
- 4. Click on Server
 - a. Go to Desktop
 - b. Click on IP configuration
 - c. Change the IPv4 address as 192.168.0.1
 - d. Go to Services
 - e. Click on the DHCP tab
 - f. Change the Default Gateway to 192.168.0.1
 - g. Change the DNS Server to 10.0.0.1
 - h. Turn on the Service
- 5. Go to PC0
 - a. Click on Desktop tab
 - b. In IP Configuration click DHCP
- 6. Repeat Step 5 for all PCs

Output:

